

Installation Instructions for Macintosh

SIGMA Photo Pro Version 2.1

System Recommended Requirements

- PowerPC G3 Processor
- Mac OS 9.2.1 or later. Mac OS X v10.1.1 or later
- 256MB RAM OS 9 or 512MB RAM Mac OS X
- 40MB of available hard disk space
- 16-bit display card (24-bit recommended)
- 800x600 monitor resolution (1024x768 recommended)
- USB or IEEE 1394 (FireWire) connection
- CD-ROM drive

To Install SIGMA Photo Pro

1. Make sure all applications are closed on your computer before downloading the software installer.
2. Download InstallSIGMAPhotoPro.app.sit on your local computer from the Sigma Web site.
3. To start the installation, make sure that the camera is not connected to the computer. Make sure the camera is turned off.
4. Double-click on the InstallSIGMAPhotoPro.app.sit. If you have Stuffit Expander installed on your computer, InstallSIGMAPhotoPro.app.sit will automatically unstuff, creating the installer called "Install SigmaPhotoPro". If you don't have Stuffit Expander installed on your computer, visit <http://www.stuffit.com/expander/> where the application is available for download at no cost.
5. Double-click on the "Install SigmaPhotoPro" icon.
6. The first page of the installer will be displayed. This page shows the languages available for PhotoPro. Choose the appropriate language and press the Next button.
7. After selecting the language, the second page is displayed. Press the Next button.
8. The End User License Agreement page will be displayed. Select the 'Yes' button to Accept the terms and conditions and the installer will proceed to the next window. Otherwise, press Cancel to Exit and terminate the installation process.
9. In the destination folder selection page, press the Next button to select the default path for installation or browse for a path of your own using the Choose option. After you are done, press Next to continue or press Cancel to exit the installation process.
10. An installation progress window will be displayed. You may abort the installation process at any time by pressing the Cancel button.
11. A Documentation procedure window will be displayed next. Press the Next button.
12. Press Exit to complete the installation.

NOTE: Drivers will be automatically installed after PhotoPro installation.

To Uninstall SIGMA Photo Pro

To uninstall the software on a Macintosh, double-click the Uninstaller icon in the SIGMA Photo Pro application folder.

Troubleshooting:

1. Occasionally the Firewire/1394 adapter in the computer can enter a state which requires that the computer be turned off in order for it to be reset. To fix this, you should shutdown your machine and then restart it.